

Preparing White Ink Cartridge for Use

For Use with the Following Cartridges

- 80430
- 90930

Items Required

- Cartridge and clear plastic clip
- Ethyl rubbing alcohol
- Lint free cloth or paper towel



Procedure

1. Ensure plastic clip is correctly fastened onto the cartridge.
2. Lightly shake cartridge for 60 seconds, the agitator should move around inside the cartridge.
3. Wet a portion of the paper towel with the Ethyl Rubbing Alcohol.
4. Remove the clear clip from the cartridge and apply light pressure to the paper towel with the print head (2 parallel white streaks should appear on the towel).
5. Place the cartridge into the printer and purge the cartridge.
6. You can now begin printing.

Trouble Shooting

- Horizontal streaks in print:
 1. Repeat steps 1 – 6 and test the print quality
 2. If print quality is still not good go to Settings → Print Side → Manual set second value to the opposite of what was previously displayed (example: if Odd change to Even, if Even change to Odd).
- Faded or no print
 1. Repeat steps 1 – 6 and test the print quality
 2. Reduce density value, purge the cartridge, and test print quality
 3. Reduce resolution value, purge the cartridge, and test print quality

Short and Long Term Storage Procedures

- Short term storage (end of day): remove from printer and replace clear plastic clip. Set in upright position and store in a cool dry environment.
- Long term storage (more than 1 week): remove from printer and replace clear plastic clip. Seal in a plastic bag and store in the upright position in a cool dry environment.